

SIGNAL PROCESSING IN MNE: DAY 2

3 – INDEPENDENT COMPONENT ANALYSIS

THE ICA CLASS



08.02.2024

Thomas S. Binns

thomas-samuel.binns@charite.de

EINSTEIN
CENTER
Neurosciences




Brain and
Data Science
QAI LABS




Signal contamination by artefacts

Ocular activity in
EEG/MEG recordings


Cardiac activity in
EEG/MEG recordings




Sensor data is a mix of sources




Data decomposition with ICA



Data reconstruction



Data reconstruction



Independent component analysis

[Install](#) [Documentation](#) [API Reference](#) [Get help](#) [Development](#)

Section Navigation

[Most-used classes](#)[Reading raw data](#)[File I/O](#)[Creating data objects from arrays](#)[Exporting](#)[Datasets](#)[Visualization](#)[Preprocessing](#)[Events](#)[Sensor Space Data](#)[Covariance computation](#)[MRI Processing](#)[Forward Modeling](#)[Inverse Solutions](#)[Source Space Data](#)[Time-Frequency](#)

mne.preprocessing.ICA

```
class mne.preprocessing.ICA(n_components=None, *, noise_cov=None, random_state=None,
method='fastica', fit_params=None, max_iter='auto', allow_ref_meg=False,
verbose=None)
```

[\[source\]](#)

Data decomposition using Independent Component Analysis (ICA). This object estimates independent components from `mne.io.Raw`, `mne.Epochs`, or `mne.Evoked` objects. Components can optionally be removed (for artifact repair) prior to signal reconstruction.

Warning

ICA is sensitive to low-frequency drifts and therefore requires the data to be high-pass filtered prior to fitting. Typically, a cutoff frequency of 1 Hz is recommended.

Parameters:

n_components : `int` | `float` | `None`

Number of principal components (from the pre-whitening PCA step) that are passed to the ICA algorithm during fitting:

- `int`

Must be greater than 1 and less than or equal to the number of channels.

Onto the notebook...

Conclusion

- ICA is a tool for decomposing data into independent components
- Unwanted components can be discarded when reconstructing data, as a tool for artefact removal
- ICA can be performed in MNE using the `ICA` class